

Mount the 25 pole d-sub connector. Observe the orientation. Use the supplied mounting kit. Plug in the ribbon cable connector to the green circuit board. See the red marking on the photo below. You may need to remove the board. If you remove the board, please don't overtighten the screws when you put the board back in place.

