

Remove the blind panel and mount the program selector in its place. Plug in the ribbon cable to the corresponding connector on the green circuit board. See the red marking on the photo below.

